



My 2-In-1 Liner & Shadow 14.237.01 C152

A multi-use product answering to mixology trend



LUCAS MEYER
COSMETICS
by Clariant

RICHNESS

PROCESS

APPLICATION



FORMULATION FEATURES

- Multi-use product
- Light and cool gel-cream texture
- Silicone-like skin feel
- Active makeup

FUNCTIONAL INGREDIENTS

Ecogel™ (2.5%) – Emulsi-gelling agent

- Amazing silicone-like skin feel
- Ultra-slippery and soft
- Homogeneous color

ACTIVE INGREDIENTS

Capixyl™

- Provides fuller, thicker and healthier eye lashes

INGREDIENT

INCI NAME

SUPPLIER

FUNCTION

%

A

Deionized Water
Dermofeel® PA-3
Blanc Covasop W9775

Water
Sodium Phytate (and) Water (and) Alcohol
CI 77891 (and) Propylene Glycol (and) Silica

-
Dr Straetmans
Sensient® Cosmetic
Technologies
Sensient® Cosmetic
Technologies
Nanhang

Vehicle
Chelating agent
Pigment

74.60
0.10
3.00

Black Covasop W9774

CI 77499 (and) Propylene Glycol (and) Silica

PVP/VA64 Cosmetic
Grade
Ecogel™

PVP/VA Copolymer

**Lysolecithin (and) Sclerotium Gum (and)
Xanthan Gum (and) Pullulan**

Lucas Meyer Cosmetics

Gelling agent

2.50

B

Schercemol® PDD
Vitapherole® E-1000

Diisostearoyl Polyglyceryl-3 Dimer Dilinoleate
Tocopherol (and) Helianthus Annuus (Sunflower)
Seed Oil

Lubrizol
VitaeNaturals

Emollient
Antioxidant

2.00
0.20

Cetiol® CC
Alphaflow® 30
Koboguard 5400 IDD

Dicaprylyl Carbonate
Hydrogenated Polydecene
Hydrogenated Polycyclopentadiene (and)
Isododecane

BASF
Aiglon
Kobo

Emollient
Emollient
Film former

2.00
2.00
1.00

C

KTZ® Misterioso
Pewter
Capixyl™

Mica (and) Titanium Dioxide (and) Iron Oxides
(C.I. 77499)
**Butylene Glycol (and) Water (and) Dextran
(and) Acetyl Tetrapeptide-3 (and) Trifolium
Pratense (Clover) Flower Extract**

KOBO
Lucas Meyer Cosmetics

Pearls
Active ingredient

8.00
2.50

Verstatil PC

Phenoxyethanol (and) Caprylyl Glycol

Dr Straetmans

Preservative

1.00

Manufacturing Procedure:

1. Mix the ingredients of phase A and heat up to 75°C. Maintain under stirring for about 30 minutes.
2. Prepare phase B: mix the ingredients of phase B and heat up to 75°C.
3. Pour phase B into phase A and homogenize under maximum stirring for 2 minutes (rotor stator homogenizer).
4. Cool down to room temperature and add the ingredients of phase C

Formula Specifications at D1:

Aspect: Silver gel cream
Viscosity (Rheo ELV 8, spindle 4, 6 rpm, 3 min): 20 000
- 30 000 Cp
pH: 6.5 - 7.0

Preservative efficacy test: Pass

Pilot batch: 6 kg

Stability Tests: On lab batch up to 1kg

1 month at 50°C
3 months at: Room Temperature, UV, 4-8°C and 45°C
D1 Centrifugation (3000 rpm, 20 min)

S U P P L E

Information and suggestions with respect to the composition or use of our products are provided in good faith based on the state of our current technical and scientific knowledge, but without any undertaking or guarantee from ourselves or our suppliers as to their relevance, accuracy, presentation or use, or the suitability of our products for any specific purpose. Such information and suggestions shall not be deemed to grant to anyone any license on patents or other intellectual property rights. We do not guarantee that the use made of our products (alone or in combination with other products), information and suggestions will respect the intellectual property rights of third parties. Users of our products shall themselves determine the suitability of our products for their intended use and, as the case may be, obtain the required regulatory approvals for the commercialization of their finished products. Users of our products, information and suggestions shall do so at their own risk and we will therefore accept no liability whatsoever with respect thereto.